

## *USB to Serial: The configuration software instructs to press the Config button, where do I find it? How do I install the drivers?*

It's easy to find the Config button: Just purchase a USB-COM PRO device.

The configuration software you've started is only for configuration of [USB-COM PRO](#), not your USB-COM device from the Industrial or Commercial line.

Drivers are usually installed by starting the "CDM installation executable" from the CD-ROM. Or by executing the [downloaded driver](#) from the vscom.de website. You may also download and expand the "CDM Release" package, and guide the Windows Hardware Wizard to find this driver.

On Windows 7 typically the driver installs direct from Windows Update, if the system has access to Internet.

Â

*Unique solution ID: #1057*

*Author: Service*

*Last update: 2011-03-23 11:26*